TT19SI 4G Real-Time Temperature and Humidity Data Logger

User Guide V1.0



1. Product overview

TT19SI is a global 4G real-time temperature and humidity data logger with high-quality sensitive components and high measurement accuracy. It is embedded with 4G modules. The data is sent to the cloud through the 4G network for monitoring and analysis, and it's also with the function of automatically generating PDF reports. With 4000mAh large capacity battery and low power consumption design, once charge, TT19SI can work for a long time, it's greatly adapt to different transportation temperature monitoring requirements.

Considering about the data security, TT19SI not only uploads data to cloud, but also stores data into flash. And for emergency use, the user can easily connect the USB C port to automatically generate PDF report. With a complete cold chain visibility, traceability monitoring (temperature, humidity, light, shock, location) system, the TT19SI is helping customers digitize their supply chain, prevent the loss of shipments with in-transit visibility and alerts, automate and increase compliance, and speed up product release, extremely improve transportation efficiency and reduce product losses.

2. Product features

- 1. Global use, support LTE with 2G fallback.
- 2. Real-time monitor temperature, humidity, light, shock and location.
- 3. Multi-use, with 4000mAh rechargeable battery.
- 4. High accuracy SHT30 digital temperature and humidity sensor with NIST traceable calibration.
- 5. IP64 waterproof design adapt to harsh environments.
- 6. Two button design with large LCD display, friendly use and easily operate.
- 7. Automatically generate PDF report via USB C port for emergency use.

3. Product specifications


Items	Details
Monitoring information	Temperature, humidity, location, light, vibration
Temperature and humidity sensor	Sensirion SHT30
Temperature measurement range	-20°C∼+60°C
Temperature accuracy range	± 0.3 °C (0°C ~ +60°C); ± 0.5 °C for other range
Humidity measurement range	5%~95%RH
Humidity accuracy range	±3%(10%~90%RH); ±5% for other range
Light sensor range	0-64000lux
Vibration sensor range	0-16G
Minimum unit	0.1℃/0.1%RH/1 lux/0.001G
Position type	LBS base station position
Memory capacity	17,000
Network system	Global LTE 4G, with 2G fallback
Recording interval	Default 15min, configurable
Reporting interval	Default 60min, configurable
Usage time	Once fully charged, it can be used for 120 days based on reporting interval of 60 min
Battery specification	Bulit-in3.7v/4000mAh Lithium rechargeable
USB interface	USB-C
Usage type	Multiuse+rechargeable
Waterproof level	IP64
Dimension	100mm*66mm*29mm
Weight	165g

4. Product description



Items	Functions							
OK Light	Indicate device status							
Alarm Light	Indicate device status							
LCD Screen	Display screen							
START/STATUS Button	Turn on/View Machine Status/Send Data							
STOP Button	Turn off/View Machine Status							
ID	Device ID number							
Light Sensor	Light sensor							
	USB-C interface, for charging or automatically							
USB-C	generating PDF report. The two LED will be on							
	during charging and off when fully charged.							

5. LCD display instructions




Serial	Functions	Explanation
Number		
1	Network signal	Indicating signal strength, the more signal bars, the better
	strength icon	signal strength.
2	4G network icon	Indicate the device connected with 4G network.
3	Flight mode icon	It means the device has entered into flight mode, and it will
		only store data but not transmit.
4	Temperature and	Exceed the upper limit: ↑
	humidity exceeding	Exceed the lower limit: ↓
	the limits	Both exceed: ↑↓
5	USB icon	Indicate the USB connected and battery charging, when
		full charged, the USB icon will not display.
6	Battery status	The higher the number of grids, the higher the electricity.
		Please charge immediately when there is only 1 grid or
		space.
7	Record icon	It means that device is in a record state, displayed after turn
		on.
8	Maximum icon	Display the maximum temperature and humidity value.
9	Minimum icon	Show the minimum temperature and humidity value.
10	Temperature and	Normal: √ Alarm: ×

	humidity alarm icon	
11	Temperature and	The resolution of temperature and humidity is 0.1. When
	humidity value	the sensor is abnormal, it will display
12	Temperature unit icon	Temperature unit, optional "C" or "F" display
13	Humidity unit icon	Humidity unit is "%".

6. Device operation and status

6.1 Turn on

In off state, press the "START" button more than 3 seconds, the "OK" LED will light in green, and the LCD display will show temperature values which means you've turned on the device, and device will upload a data to cloud immediately.



6.2 Turn off

In on state, press the "STOP" button more than 3 seconds, the "Alarm" LED will light in red and the LCD display will be off, which means you've turned off the device, and device will upload a data to cloud immediately.



6.3 No alarm

After turning on without alarm, the "OK" led will flash in green once every 10 seconds.

6.4 Alarm

6.4.1 Temperature and humidity alarm

After turning on, if temperature or humidity alarm, the "Alarm" led will flash in red once every 10 seconds and the LCD will display the temperature and humidity alarm mark, device will upload a data to cloud immediately.

6.4.2 Shock alarm

After turning on, If shock alarm, and device will upload a data to cloud immediately.

6.4.3 Light alarm

After turning on, If light alarm, and device will upload a data to cloud immediately.

Note: Each type of alarm will be triggered only once in every data recording cycle.


6.5 Query status

Current status	Operating	Indicator light status	LCD display
Initialization	Short press "Start" or "Stop" button	/	OFF
Start recording	Long press the start button for more than 3s	The green light lit continuously for 5s	Real-time data
Stop recording	Long press the stop button for more than 3s	The red light lit continuously for 5s	End
Recording and no alarm occurred	/	The green light flashes once every 10 seconds	Display "√"
Recording and the alarm occurred	/	The red light flashes once every 10 seconds	Display " \times " Display " \uparrow " or " \downarrow "
Generate report	Insert the device into USB and are generating a report	The red and green lights flashed alternately	Display End or OFF
USB status	Insert the device into USB, and the report has been generated	The red and green light is always on.	Display End or OFF

After turning on the device, if short press the "START" button, the device will be awakened and immediately send a data to cloud. If no alarm, the "OK" LED will flash in green, if alarm, the "Alarm" LED will flash in red.

Continuously pressing the button will toggle the display screen, in the order of "temperature value → humidity value → maximum temperature value → maximum humidity value → minimum temperature value → minimum humidity value."


Note: When toggling the display screen, short press the "STOP" button to toggle directly to the "temperature value" display screen. If there is no operation within 10 seconds, the LCD display will be off.




7. Data query


Tzone temperature and humidity cloud platform website: http://cloud.tzonedigital.com/

After turning on, the device data can be queried on TZONE cloud platform. Before entering the cloud platform, you will need to register an account. Once registered, log in and navigate to the "Device Management" section to add the TT19SI ID.




Light 2024-04-12 09:31 ~ 2024-04-12 09:39






Shipment ID	Customer company	
Asset ID	Goods	
Carrier	Transport Route	,
Sender	Receiver	
/ehicle		
EstimatedTime 2024/04/12	99:29:00~2024/06/11 09:29:00	
Remark		
evice Settings		
Reporting Interval (min)	60 Recording Interval (min)	1
Start Delay Time (min)	0 Open GPS	Enabl
Forbid manual stop	No Set Airplane Mode	Disable
SOUTH SECOND SEC		




8. PDF report data query

After using the USB cable provided by our company to connect the device to one computer, the computer reads the disk and automatically generates the PDF report. If the real -time data of the device cannot be queried, the historical data of the device can be viewed through the PDF report:

Note: The device must end trip before generating a PDF report.





Temperature&Humidity Table

Date	Time	.C	%RH	Date	Time	,C	%RH	Date	Time	.c	%RH	Date	Time	,C	%RH	Date	Time	,C	%RH
04/12/2024 04/12/2024 04/12/2024 04/12/2024 04/12/2024	01:12:41 01:17:37 01:18:58 01:22:52	26.5 26.3 26.2 25.8	60.6 61.9 62.4 59.5										11811						

