# TT19SI Quick Setup Use Manual V1.0

Steps how to run the device easily.

Step1: Register an account on the TZONE cloud platform.

TZONE cloud platform Address： http://cloud.tzonedigital.com/

Step2: After registering an account, add the device ID to the account.

Step3： Device on, short press the "START" button before turning on the machine. If the LCD displays "OFF", it means the machine is turned off;At this time, press and hold the "START" button to turn on the machine, the "OK" light will be green, and the LCD will display the content, which means the machine is turned on, as shown in the figure below:

Step4: Install the device at the temperature monitoring site and send the data,if the signal grid

" 📶 " is displayed in the upper left corner of the device, it means that the machine has successfully

sent data.

Step5: Query data.

Query method 1：

Query method 2：

Query method 3：

Enter the URL: http://cloud.tzonedigital.com/

DIGITAL TECHNOLOGY
TZONE

℃ ▾   English ▾   ⤷ Quit

Device ID : **190023000000002**

Temperature
27.1℃

Humidity
72%

Light
24lux

Vibration
0mg

Battery
38%

2023/09/15 11:11:27

☑ Chart   ⊞ List

2023/09/08 11:29   2023/09/15 11:29   View   Download

Chart

Chart
2023-09-08 11:27 ~ 2023-09-15 11:11

64.73 % (Humidity)

26.05 ℃ (Temperature)

Wednesday, Sep 13, 17:45-17:59

12:00 9. Sep 12:00 10. Sep 12:00 11. Sep 12:00 12. Sep 12:00 13. Sep 15. Sep

80
60
40
20

Light
2023-09-08 11:27 ~ 2023-09-15 11:11

67.25 lux (Light)

Monday, Sep 11, 10:15-10:29

12:00 9. Sep 12:00 10. Sep 12:00 Sep 12:00 13. Sep 12:00 14. Sep 15. Sep

100
75
50
25

Vibration

2023-09-08 11:27 ~ 2023-09-15 11:11

0.00 **mg (Vibration)** 0

| 12:00 | 9. Sep | 12:00 | 10. Sep | 12:00 | 11. Sep | 12:00 | 12. Sep | Tuesday, Sep 12, 22:30~22:44 | 00 | 14. Sep | 15. Sep |

9. Sep   10. Sep   11. Sep   12. Sep   13. Sep

Tips: The query returns a maximum of 10000 data. If it exceeds, please change the time range.

Shipment

Shipment ID	DW2827257816307	Customer company	skywalker
Asset ID		Goods	
Carrier		Transport Route	~
Sender		Receiver	
Vehicle			
EstimatedTime	2024/04/18 10:32:00~2024/06/17 10:32:00		
Remark			

Device Settings

Reporting Interval (min)	5	Recording Interval (min)	5
Start Delay Time (min)	0	Open GPS	Disabled
Forbid manual stop	No	Set Airplane Mode	Disabled
Temperature Unit	°F	Time zone	+08:00

Alarm Settings

Channel1 - Temperature alarm threshold (°C)	-40~100
Channel1 - Temperature Pre-Alert threshold (°C)	-30~90
Channel2 - Temperature alarm threshold (°C)	-10~100
Channel2 - Temperature Pre-Alert threshold (°C)	-10~90
Light alarm threshold (lux)	0~200
Vibration alarm threshold (g)	2
Effective date	2024/03/12 16:03:13~2025/03/12 16:03:13
Repeat	Sunday、Monday、Tuesday、Wednesday、Thursday、Friday、Saturday
Effective time	00:00~23:59

Channel1 - Humidity alarm threshold (%)	0~100
Channel1 - Humidity Pre-Alert threshold (%)	10~90

Alarm Notifier

Mail alarm notification

SMS alarm notification

Share information