



RXMOD-RXW-xxx

HOBOnet Manager

The HOBOnet Wireless Manager module is installed in an RX3000 station. Data is transmitted wirelessly from sensors across the network to the RX3000 station and then uploaded to HOBOLink, Onset's innovative cloud-based software platform.



Key Advantages:

- 900 MHz wireless mesh self-healing technology
- 450 to 600 meter (1,500 to 2,000 feet) wireless range and up to five hops
- Up to 50 wireless sensors per RX3000
- Plugs into RX3000 Flex Port

Wireless Mote

Operating Temperature Range	-25° to 60°C (-13° to 140°F)
Radio Power	12.6 mW (+11 dBm) non-adjustable
Transmission Range	Reliable connection to 457.2 m (1,500 ft) line of sight at 1.8 m (6 ft) high Reliable connection to 609.6 m (2,000 ft) line of sight at 3 m (10 ft) high
Wireless Data Standard	IEEE 802.15.4
Radio Operating Frequencies	RXMOD-RXW-900: 904–924 MHz RXMOD-RXW-868: 866.5 MHz RXMOD-RXW-922: 916–924 MHz
Modulation Employed	OQPSK (Offset Quadrature Phase Shift Keying)
Data Rate	Up to 250 kbps, non-adjustable
Duty Cycle	<1%
Maximum Number of Motes	50 motes per one RX Wireless Sensor Network
Power Source	Powered by the RX3000 station
Dimensions	Mote: 16.2 x 8.59 x 4.14 cm (6.38 x 3.38 x 1.63 inches) Cable length: 2 m (6.56 ft)
Weight	Mote: 159 g (5.62 oz)
Materials	Mote: PCPBT, silicone rubber seal
Environmental Rating	Mote: IP67, NEMA 6
Compliance Marks	 RXMOD-RXW-900  RXMOD-RXW-868  RXMOD-RXW-922

Contact Us



Data Logging Solutions
Australia & New Zealand

Australia
1300 186 107
sales@hobodataloggers.com.au
www.hobodataloggers.com.au

New Zealand
0800 104 904
sales@onetemp.co.nz
www.onetemp.co.nz